

# Инструкция Голень сидя Body Solid Powerline PSC43


Полезные ссылки:

Голень сидя Body Solid Powerline PSC43 - смотреть на сайте



# PSC-43X SEATED CALF RAISE

## OWNER'S MANUAL



WWW.BODYSOLID.COM

## THERE IS A RISK ASSUMED BY INDIVIDUALS WHO USE THIS TYPE OF EQUIPMENT. TO MINIMIZE RISK, YOU MUST FOLLOW THESE RULES:

Inspect equipment before each workout. Check that all nuts, bolts, screws and pop pins are in place and fully tightened. Also, before use, check cables for sign of wear. Replace all worn parts immediately. Never use machine if any parts are damaged or missing.

### FAILURE TO FOLLOW THESE RULES MAY RESULT IN SERIOUS INJURY.

Keep clear of the cables and all moving parts when machine is in use.

Always make sure all Snap Links are closed when doing cable/pulley/strap exercises. Exercise with care. Perform your exercises at a smooth moderate pace; never perform jerky or uncoordinated movements that may cause injury.

It is recommended that you workout with a training partner.

Do not allow children or minors to play on or around this equipment.

If unsure of proper use of equipment, call your local Body-Solid distributor or the Body-Solid customer service center at 1-800-556-3113.

WARNING: Consult your physician before starting your exercise program. For your own safety, do not begin any exercise program without proper instruction.

## Safety and Maintenance of Cables

**IMPORTANT:** Cables are wear items. It is your responsibility to prevent unexpected breakage. Cable inspection should be performed daily. Inspect all cables, the nylon coating on all cables, and the area near the fitting at each end of each cable. Replace any damaged or worn cable immediately. Do not allow the machine to be used until damaged or worn cables are replaced. Using or allowing a machine to be used with a suspect cable can

For Body-Solid Customer Service

information.

result in serious injury. See Owner's Manual for more

Call 1-800-556-3113

## DO NOT REMOVE WARNING LABELS FROM MANUAL OR MACHINE

# PSC-43X TABLE OF CONTENTS

• SAFETY INSTRUCTIONSPAGE	4
PREPARATIONPAGE	5
• HARDWARE LISTPAGE	6
• HARDWARE ILLUSTRATION PAGE	7
PART LIST / ILLUSTRATIONPAGE	1 🗆
• ASSEMBLY INSTRUCTIONS PAGE	12
• EXPLODED VIEWPAGE	18
• CONTACT PAGEPAGE	20

# PSC-43X SAFETY INSTRUCTIONS

WHEN USING EXERCISE EQUIPMENT,
YOU SHOULD ALWAYS TAKE BASIC
PRECAUTIONS INCLUDING THE
FOLLOWING:

- Read all instructions before using the PSC-43X.
   These instructions are written to ensure your safety and to protect the unit.
- Do not remove any safety labels from the machine.
- Do not allow children on or near the equipment.
- Use the equipment only for its intended purpose as described in this guide. Do not use accessory attachments that are not recommended by the manufacturer. Such attachments might cause serious injuries.
- Wear proper excercise clothing and shoes for your workout, no loose clothing.
- Keep hands, limbs, loose clothing, and long hair well out of the way of all moving parts
- · Use care when getting on or off the unit.
- Do no overexert yourself or work to exhaustion.
- If you feel any pain or abnormal symptoms, stop your workout immediately and consult your physician.
- Never operate unit when it has been dropped or damaged. Return the equipment to a service center for examination and repair.
- Never drop or insert objects into any opening in the equipment.
- Always check the unit and its cables before each use.
   Make sure that all fasteners and cables are secure and in good working condition.
- Do not use the equipment outdoors or near water.

#### PERSONAL SAFETY DURING ASSEMBLY

- Before beginning assembly, please take the time to read the instructions thoroughly.
- Read each step in the assembly instructions and follow the steps in sequence. Do not skip ahead. If you skip ahead, you may learn later that you have to disassemble components and that you may have damaged the equipment
- Assemble and operate the PSC-43X on a solid, level surface. Locate the unit a few feet from the walls or furniture to provide easy access.

The PSC-43X is designed for your enjoyment. By following these precautions and using common sense, you will have many safe and pleasurable hours of healthful exercise with your Powerline Seated Calf Raise Machine.

After assembly, you should check all functions to ensure correct operation. If you experience problems, first recheck the assembly instructions to locate any possible errors made during assembly. If you are unable to correct the problem, call the dealer from whom you purchased the machine or call 1-800-556-3113 for the dealer nearest you.

#### **OBTAINING SERVICE**

Please use this Owner's Manual to make sure that all parts have been included in your shipment. When ordering parts, you must use the part number and description from this Owner's Manual. Use only Powerline by Body Solid replacement parts when servicing this machine. Failure to do so will void your warranty and could result in personal injury.

For information about product operation or service, check out the official Powerline website at www.bodysolid.com or contact an authorized Powerline dealer or a Powerline factory-authorized service company or contact Body-Solid customer service at one of the following:

Toll Free: 1-800-556-3113 Phone: 1-708-427-3555 Fax: 1-708-427-3556

Email: service@bodysolid.com

Or write to: Body-Solid, Inc.
Service Department
1900 S. Des Plaines Ave.
Forest Park, IL 60130 USA

RETAIN THIS OWNER'S MANUAL FOR FURTURE REFERENCE. PART NUMBERS ARE REQUIRED WHEN ORDERING PARTS.

# PSC-43X PREPARATION

### REQUIRED TOOLS

The basic tools that you must obtain before assembling the PSC-43X include but are not limit to:

- Standard Wrench Set
- Metric Wrench Set
- Adjustable Wrench
- Standard / Metric Allen Key Set

### INSTALLATION REQUIREMENTS

Follow these installation requirements when assembling the PSC-43X:

Set up the PSC-43X on a solid, flat surface. A smooth, flat surface under the machine helps keep it level.

Provide ample space around the machine. Open space around the machine allows for easier access.

For aesthetic purposes, insert all bolts in the same direction unless specified (in text or illustrations) to do otherwise.

Leave room for adjustments. Tighten fasteners such as bolts, nuts, and screws so the unit is stable, but leave room for adjustments. Do not fully tighten fasteners until instructed in the assembly steps to do so.

Fill out and mail the warranty card.

### **ORDERING REPLACEMENT PARTS**

If you need to order replacement parts please be prepared to provide the following information when contacting us so that we can assist you better.

- 1. Model Number
- 2. Place of Purchase
- 3. Serial Number (S/N)
- 4. Part # and Description

### ASSEMBLY TIPS

Read all "Notes" on each page before beginning each step.


While you may be able to assemble the PSC-43X using the illustrations only, important safety notes and other tips may be included in the text.

Some pieces may have extra holes that you will not use. Use only those holes indicated in the instructions and illustrations.

NOTE: With so many assembled parts, proper alignment and adjustment is critical. While tightening the nuts and bolts, be sure to leave room for adjustments.

NOTE: The bottles that are marked "Poison" is your touch up paint. Keep away from children.

**CAUTION**: Obtain assistance! If you feel like you can't assemble the PSC-43X by yourself then do not attempt to do so as this could result in injury. Review the Installation Requirements before proceeding with the following steps.




# PSC-43X HARDWARE LIST

PART #	SIZE	DESCRIPTION	QUANTITY
1	1/2"X3 1/2"	HEX HEAD BOLT	1 PCS.
2	M12X80mm	HEX HEAD BOLT	2 PCS.
3	M10X70mm	HEX HEAD BOLT	6 PCS.
4	5/16"X2 3/4"	HEX HEAD BOLT	2 PCS.
5	1/2"	NYLON LOCK NUT	1 PCS.
6	M12	NYLON LOCK NUT	2 PCS.
7	M10	NYLON LOCK NUT	6 PCS.
8	M10	WASHER	4 PCS.
9	5/16"	WASHER	2 PCS.
10	5/16"	SPRING WASHER	2 PCS.
11	2"X2"	FOOT CAP	4 PCS.
12	2"X2"	END CAP	4 PCS.
13	1 3/4"X1 3/4"	END CAP	2 PCS.
14	Ø48mm	ROUND END CAP	2 PCS.
15	Ø1"	ROUND END CAP	4 PCS.
16	50X45mm	NYLON BUSHING	1 PCS.
17	Ø1"X5"	RUBBER GRIP	1 PCS.
18		RUBBER BAR CUSHION	1 PCS.
19		RING PIN	1 PCS.
20	95X140mm	NO-SLIP TAPE	2 PCS.
21	Ø3 1/2"X8"	FOAM ROLLER	2 PCS.




## KEY#55 HEX HEAD BOLT 3/8" X 2 1/2" PARTIAL THREAD QTY 6 PART #1 1/2"X 3 1/2" HEX HEAD BOLT QTY. 1 uuuuuuuu PART #2 M12X80MM HEX HEAD BOLT QTY. 2 PART #3 M10X70MM HEX HEAD BOLT **GTY.** 6 KEY #57 HEX HEAD BOLT 5/16" X 1/2" PARTIAL THREAD QTY 1 th in in my PART #4 5/16"X2 3/4" HEX HEAD BOLT QTY. 2 "FULL THREAD QTY 2 PART #5 1/2" NYLON LOCK NUT QTY. 1 DUUDUUU mm o 10 20 30 50 60 70 80 90 100 110 120 130 140 150 inch

KEY#55 HEX HEAD BOLT 3/8" X 2 1/2" PARTIAL THREAD QTY 6




## HARDWARE ILLUSTRATION

PART #11	2"X2" FOOT CAP	<b>Q</b> тү. 4
PART #12	2"X2" END CAP	<b>Q</b> тү. 4
PART #13	1 3/4"X1 3/4" END CAP	<b>Q</b> ТҮ. 2
PART #14	48MM DIA. ROUND END CAP	<b>Q</b> тү. 2
PART #15	1" DIA. ROUND END CAP	<b>Q</b> тү. 4
PART #16	50X45MM NYLON BUSHING	<b>Q</b> ТҮ. 1
PART #17	1" DIA.X5" RUBBER GRIP	<b>Q</b> ТҮ. 1
PART #18	RUBBER BAR CUSHION	<b>Q</b> тү. 1
PART #19	QUICK RELEASE RING PIN	<b>Q</b> ТҮ. 1
PART #20	95X140MM NO-SLIP TAPE	<b>Q</b> ТҮ. 2
PART #21	3 1/2" DIA.X8" FOAM ROLLER	Qтү. 2




PART A
SUPPORT FRAME
[1pcs]




PART B


MAINFRAME
[1PCS]




WEIGHT HOLDER



PART D
RING PIN FRAME
[1PCS]





ROLLER ADJUSTER



PART F
FOOT FRAME
[1PCS]







NOTE: WEIGHT ROD (I) IS 500MM LONG AND ROLLER ROD (K) IS 445MM LONG




## BE CAREFUL TO ASSEMBLE ALL COMPONENTS IN THE SEQUENCE THAT THEY ARE PRESENTED.

## NOTE:


FINGER TIGHTEN ALL HARDWARE IN THIS STEP. DO NOT WRENCH TIGHTEN
UNTIL THE LAST STEP. SOME COMPONENTS MAY BE PRE-ASSEMBLED.
NYLON LOCK NUTS WILL NOT FULLY SCREW ONTO BOLTS, MUST WRENCH TIGHTEN.

- 1 A. ATTACH BASE FRAME (H) TO MAINFRAME (B) USING:
  - 2 (#3) M10X70MM HEX HEAD BOLT
  - 2 (#8) M10 WASHER
  - 2 (#7) M10 NYLON LOCK NUT
- 1B. ATTACH SEAT FRAME (G) TO MAINFRAME (B) USING:
  - 2 (#3) M10X70MM HEX HEAD BOLT
  - 2 (#8) M10 WASHER
  - 2 (#7) M10 NYLON LOCK NUT
- 1 C. ATTACH FOOT FRAME (F) TO MAINFRAME (B) USING:
  - 2 (#3) M10X70MM HEX HEAD BOLT
  - 2 (#7) M10 NYLON LOCK NUT
- 1 D. INSERT FOOT CAPS ONTO ENDS OF BASE FRAME (H) AND SEAT FRAME (G) USING:
  - 4 (#11) 2"X2" FOOT CAP
- 1E. INSERT END CAPS INTO ENDS OF FOOT FRAME (F) USING:
  - 2 (#14) 48MM DIA. ROUND END CAP
- 1 F. INSERT NO-SLIP TAPE ON TOP SURFACE OF FOOT FRAME (F) USING:
  - 2 (#20) 95X140MM NO-SLIP TAPE





ABOVE SHOWS STEP 1
ASSEMBLED AND COMPLETED






## BE CAREFUL TO ASSEMBLE ALL COMPONENTS IN THE SEQUENCE THAT THEY ARE PRESENTED.


## NOTE:

FINGER TIGHTEN ALL HARDWARE IN THIS STEP. DO NOT WRENCH TIGHTEN
UNTIL THE LAST STEP. SOME COMPONENTS MAY BE PRE-ASSEMBLED.

NYLON LOCK NUTS WILL NOT FULLY SCREW ONTO BOLTS, MUST WRENCH TIGHTEN.

- ZA. INSERT END CAP, ATTACH RUBBER BAR CUSHION, AND SLIDE ON RUBBER GRIP TO WEIGHT HOLDER (C) USING:
  - 1 (#12) 2"X2" END CAP
  - 1 (#18) RUBBER BAR CUSHION
  - 1 (#17) 1" DIA.X5" RUBBER GRIP
- 2B. ATTACH WEIGHT HOLDER (C) TO MAINFRAME (B) USING:
  - 1 (#2) M12X80MM HEX HEAD BOLT
  - 1 (#6) M12 NYLON LOCK NUT
- 2C. ATTACH SUPPORT FRAME (A) TO SEAT FRAME (G) USING:
  - 1 (#1) 1/2"X 3 1/2" HEX HEAD BOLT
  - 1 (#5) 1/2" NYLON LOCK NUT
- 2D. ATTACH SEAT PAD (J) TO SUPPORT FRAME (A) USING:
  - 2 (#4) 5/16"X 2 3/4" HEX HEAD BOLT
  - 2 (#10) 5/16" SPRING WASHER
  - 2 (#9) 5/16" WASHER
- 2E. INSERT END CAPS INTO BOTH ENDS OF SUPPORT FRAME (A) USING:
  - 2 (#12) 2"X2" END CAP
- 2F. INSERT WEIGHT ROD (I) INTO OPENING AT FRONT OF SUPPORT FRAME (A), SECURE BY TIGHTENING M10X25MM BOLT AND NUT AND INSERT END CAPS INTO ENDS OF WEIGHT ROD USING: 2 (#15) 1" DIA. ROUND END CAP.







## BE CAREFUL TO ASSEMBLE ALL COMPONENTS IN THE SEQUENCE THAT THEY ARE PRESENTED.


## NOTE:

FINGER TIGHTEN ALL HARDWARE IN THIS STEP. DO NOT WRENCH TIGHTEN
UNTIL THE LAST STEP. SOME COMPONENTS MAY BE PRE-ASSEMBLED.
NYLON LOCK NUTS WILL NOT FULLY SCREW ONTO BOLTS, MUST WRENCH TIGHTEN.


- 3A. INSERT END CAP INTO BOTTOM OPENING AND SLIDE NYLON BUSHING ONTO TOP OPENING OF RING PIN FRAME (D) USING:
  - 1 (#12) 2"X2" END CAP
  - 1 (#16) 50X45MM NYLON BUSHING
- 3B. ATTACH RING PIN FRAME (D) TO SUPPORT FRAME (A) USING:
  - 1 (#2) M12X80MM HEX HEAD BOLT
  - 1 (#6) M12 NYLON LOCK NUT
- 3C. INSERT END CAPS INTO BOTH ENDS OF ROLLER ADJUSTER (E) USING:
  - 2 (#13) 1 3/4"X1 3/4" END CAP
- 3D. SLIDE ROLLER ADJUSTER (E) INTO RING PIN FRAME (D) AND SECURE USING:
  - 1 (#19) QUICK RELEASE RING PIN
- 3E. SLIDE ROLLER ROD (K) INTO OPENING OF RING PIN FRAME (D)

  AND INSERT A FOAM ROLLER AND ROUND END CAP ONTO EACH

  SIDE OF ROLLER ROD (K) USING:
  - 2 (#21) 3 1/2" DIA.X8" FOAM ROLLER
  - 2 (#15) 1" DIA. ROUND END CAP



PSC-43X
EXPLODED VIEW





## P5C-43X

### PLEASE WRITE YOUR SERIAL NUMBER IN THE BOXES BELOW

S/N # 0000-00-00-00-00-00



<sup>©</sup> Copyright 2011. Body-Solid. All rights reserved. Body-Solid reserves the right to change design and specifications when we feel it will improve the product. Body-Solid machines maintain several patented and patent pending features and designs. All rights reserved on all design patents and utility patents.