


Инструкция Разгибание ног сидя Body Solid PRO CLUB LINE SLE200G-3

Полезные ссылки:


Разгибание ног сидя Body Solid PRO CLUB LINE SLE200G-3 - смотреть на сайте Разгибание ног сидя Body Solid PRO CLUB LINE SLE200G-3 - читать отзывы

SLE-200G LEG EXTENSION THERE IS A RISK ASSUMED BY INDIVIDUALS WHO USE THIS TYPE OF EQUIPMENT. TO MINIMIZE RISK, YOU MUST FOLLOW THESE RULES: 1. Inspect equipment before each workout. Checke that all nuts, bolts, screws and pop pins are in place and fully tightened. Also, before use, check cables for signs of wear. Replace all worn parts immediately. Never use machine if any parts are damaged or missing. Failure to follow these rules may result in serious injury. 2. Keep clear of the cables and all moving parts when the machine is in use. 0 DEC EXTENSION 3. Always make sure all Snap Links are closed when doing any cable/pulley exercises. Exercise with care. Perform your exercises at a smooth moderate pace; never perform jerky or uncoordinated movements that may cause injury. 5. It is recommended that you should workout with a training partner.6. Do not allow children or minors to play on or around this equipment. 7. If unsure of proper use of equipment, call your local Body-Solid distributor or the Body-Solid customer service department at 1-800-556-3113. 8. WARNING: Consult your physician before starting your exercise program. For your own safety. do not begin any exercise program without proper instruction. RAL2-11-98 RAL2-11-98 VERSION 200505



SLE-200G PARTS ILLUSTRATION SHEET A [1PCS] WEIGHT STACK FRAME D [1PCS] MAIN BODY FRAME I [1PCS] ROLLER BAR FRAME H [1PCS] TOP PULLEY FRAME [1PCS] BOTTOM PULLEY FRAME F [1PCS] J [1PCS] HANDLE BAR ADJUSTABLE BACK SUPPORT C [1PCS] MIDDLE SUPPORT FRAME G [1PCS] BACK PAD FRAME E [1PCS] LEG EXTENSION FRAME 000000000 K [2PCS] CHROME GUIDE ROD O [1PCS] SEAT PAD P [1PCS] BACK PAD L-1 [1PCS] M [3PCS] N [2PCS] FOOT ROLLER BAR 2"X8" PLATE (Ø1"X610L) SEAT BRACKET Q [1PCS] BACK PAD RUBBER

PAGE 2



SLE-200G LEG EXTENSION ASSEMBLY STEPS

STEP-1

NOTE: DO NOT TIGHTEN NUTS AND BOLTS SECURELY UNTIL YOU HAVE COMPLETED ALL ASSEMBLY STEPS.

- □ Attach A Weight Stack Frame and D Main Body Frame to B Bottom Pulley Frame.
- □ Attach C Middle Support Frame to A Weight Stack Frame and D Main Body Frame.
- $\ \square$ Attach **E** Leg Extension Frame to **D** Main Body Frame.
- \square Attach **F** Adjustable Back Support and **J** Handle Bar to **D** Main Body Frame.

STEP-2

- □ Attach N Seat Brackets to D Main Body Frame.
- □ Attach O Seat Pad to D Main Body Frame and N Seat Brackets.
- \square Attach **P** Back Pad to **D** Main Body Frame.
- \square Slide **G** Back Pad Frame into **F** Adjustable Back Support.

CAUTION: DO NOT OVERTIGHTEN PAD BOLTS.

OVERTIGHTENING WILL STRIP

T-NUTS IN THE WOOD.

STEP-3

- □ Attach K Chrome Guide Rods and D6 Rubber Donuts to A Weight Stack Frame
- □ Slide Weight Stack and **D18** Chrome Top Plate onto K Chrome Guide Rods.
- □ Attach H Top Pulley Frame to A Weight Stack Frame and attach D10 Shaft Collar.
- □ Slide I Roller Bar Frame E Leg Extension Frame.
- □ Slide L Foot Roller Bar into I Roller Bar Frame
- □ Attach **D17** Foam Rollers.

STEP-4

- □ Attach Pulleys and Cables as shown.
- □ Attach End Caps and Grips.
- □ TIGHTEN ALL NUTS AND BOLTS SECURELY.
- □ Attach Bolt Caps.

SAFETY RULES

- 1. Periodically check that all nuts, bolts and screws are fully tightened on your LEG EXTENSION MACHINE.
- 2. Exercise with care.Perform your exercises at a smooth moderate pace; never perform jerky or uncoordinated movements that may cause injury.
- 3. It is recommended that you should workout with a training partner.
- 4. Warning: CONSULT YOUR PHYSICIAN BEFORE STARTING YOUR EXERCISE PROGRAM. IT IS ADVISABLE TO HAVE A PHYSICAL EXAMINATION BEFORE YOU ENTER ANY EXERCISE PROGRAM. FOR YOUR OWN SAFTEY, DO NOT BEGIN ANY EXERCISE WITHOUT PROPER INSTRUCTION.

SLE-200G LEG EXTENSION 20X3tX25L=8PCS Ø. Ø. 0 0 PAGE 5